

IM213D-LM
0116
0002

Metered Oil Control Gun L-MOGF

Instruction Manual



To the Owner

PLEASE READ THIS INFORMATION CAREFULLY BEFORE USE.

Read and retain this instruction manual to assist you in the operation and maintenance of this product.

If you have any problems with the meter, refer to the maintenance and trouble shooting sections of this manual.

This manual contains connection and operating instructions for meters with Liquid Crystal displays (LCD).

If you need further assistance, please contact your local representative or distributor for advice.

This Flow Meter has incorporated the oval rotor principal into its design. This has proven to be a reliable and highly accurate method of measuring flow.

Exceptional repeatability and high accuracy over a wide range of fluid viscosities and flow rates are features of the oval rotor design. With a low pressure drop and high pressure rating oval rotor flow meters are suitable for both gravity and pump (in line) applications.

Important Information



WARNING

Before use, confirm the fluid to be used is compatible with the meter. Refer to Industry fluid compatibility charts or consult your local representative for advice.

Operating Principle

When fluid passes through the meter the rotors turn, as shown below. The magnets which are located in the rotors will pass across the PCB sensors.

A signal is generated which is then sent by the PCB to the relevant LCD, or receiving instrument as a Pulse Output.



Operational Overview

1. During normal operation the 6 Figure LCD display will appear as per the example diagram below.



2. Pressing the 'Mode' button will enable the operator to toggle between the following two Display options.

- Batch
- Total

3. The 'Batch' total can be reset by pressing the 'Reset' button.

Please note:

This function resets the 'Batch' only. The 'Total' displayed is unable to be reset.

4. A 'Sleep' mode has been incorporated in the meter to prolong battery life. The unit will activate sleep mode after 30 secs without use.

Programming Instructions



Note

Any changes made during the programming phase will automatically be 'Saved' when the unit is returned to the operation mode

Accessing 'Programming' Menu

To enter in the programming 'Menu', press the reset button for 5 secs.

Once in the programming menu the operator will be able to access (and adjust) 3 programming selections.

- 1- Setting Decimal Place
- 2- Display Units of measurement
- 3 - Calibration Mode

Setting the decimal place.

1. The unit will display the mode and the number of Decimal Places currently set.

E.g. 'dEC .22'

2. Pressing the black 'Mode' button will cycle through options available

- dEC .1 = 1 Decimal Place
- dEC .22 = 2 Decimal Places
- dEC .333 = 3 Decimal Places

3. To move to the next section (Unit) press the 'Reset' button

Setting the Units for both Batch & Total.

1. The LCD will now display 'UNIT'.
See 'Operational Overview'.

2. Pressing the 'Mode' button will cycle through the options of units that can be displayed for Batch.

- L
- GAL
- Qt
- Pt
- Oz
- dL

3. Next press the 'Reset' button to move onto setting the 'Total' units. The available unit options are as shown above.

4. Once the required 'Units' have been selected move to the next section (Calibration) by pressing the 'Reset' button.

Programming Instructions cont.

Calibration.

The calibration mode enables, in the case the operator suspects the accuracy of the meter is in question, the operator to dispense a known volume of fluid through the meter (Test Volume). This Test Volume is compared to the volume measured by the meter (Measured Volume). The meter will perform an 'Auto Calibration' if applicable.

1. The unit will display 'CALIBRATE' in the lower left hand corner, and a number on the main display.

The following options can be scrolled through by pressing the *Mode* button

- 2
- 4
- 8
- 20
- 100
- 250

This number represents the 'Test Volume' to be dispensed through the meter during Calibration.

2. On selecting the 'Test Volume' press the *Mode* button for 3 secs.

The meter will display 'PURGE' and 'CALIBRATE' will also start to flash.

3. Purge the system of air by running fluid through the system.

4. Once purged of air the calibration process can be started by pressing the *Mode* button.

The unit will display **RUN** and the 'Test Volume'.
E.g. **RUN 100**

5. Run the Test Volume through the meter until stipulated volume has been reached (e.g. 100).

6. Once this volume has been reached press the *Mode* button to stop the test.

The unit will now compare the 'Measured Volume' to the 'Test Volume' and perform an 'Auto Calibration' if the difference between the two volumes are within $\pm 8\%$ of each other.

Note:

If the difference between the two volumes is greater than $\pm 8\%$ of each other, the unit will display one of the following messages..

- ERROR LOW
- ERROR HIGH

if these messages are displayed please contact your Lubemate agent for advice.

Returning to 'Operation' Mode

At any stage the unit can be returned to the 'Operation' mode by pressing the 'Reset' button for approx. 3 secs.

Any program changes will automatically be saved.

Maintenance Procedures.

Disassembly

Ensure that the fluid supply to the meter is disconnected, and the line pressure is released before disassembly, with the exception for repair or maintenance to the LCD or PCB where it is not necessary to isolate the meter from flow. Refer to the exploded parts diagram on subsequent pages for item numbers.

1. Pull off protective boot (item 1) and unscrew the four retaining screws (item 2) next remove the Electronic Module (item 3)

2. Check for evidence of moisture into the electronic housing. If there is evidence of this, check the condition of the O-Ring (item 4)

3. To access the Rotor assembly, remove the 8 Meter Cap screws (item 9)

4. Remove the rotors (item 6) and inspect the condition of each.

Also investigate if there is the presence of any foreign material in the meter body, that may inhibit the rotors performance


Reassembly

1. Please note, the design of the rotor and shaft assembly ensures that the rotors can only be re-installed with the correct orientation. (i.e. with the magnets being in close proximity to the Electronic module).

When replacing the rotors the top face of the rotors should be flush with the sealing face of the meter body. If they sit higher than the sealing face remove, turn over and replace.

2. Replace the rotors (Item 6) onto the shafts at 90 degrees to each other (as per diagram below) and check their operation by turning either of the rotors.

If the rotors are not 'in mesh' correctly or do not move freely, remove one of the rotors and replace correctly at 90 degrees to the other rotor.




Maintenance Procedures

3. Check the Rotors (item 6) rotate freely.
4. Replace the O-Ring (item 7) into the groove of the Meter Cap (item 8).
5. Replace the Meter Cap onto Meter Body (item 5)
Tighten Meter Cap screws (item 9) in a diagonal sequence
E.g. 1, 5, 3, 7, 4, 8, 6, 2
6. Place the O-Ring (item 4) into the Electronic Module (item 3) and mount the Electronic module onto to the Meter Body
7. Replace and tighten the Retaining Screws (item 2) in diagonal sequence.
8. Align and push on the protective boot (item 1) onto the electronic module (item 3).
9. Before returning to service test the meter by turning the Rotors with your finger. Or applying a very low air pressure (no more than a good breath) to the meter

Changing the Battery.


A 'Low Battery' warning will be displayed on the LCD screen when there is 5% power left. The warning will remain active until the battery is replaced.

1. See 'Disassembly' procedure.
Follow step 1 to isolate the Electronic module.
2. See 'Photograph' below.
Remove the PCB from clear plastic housing by unscrewing the 3 retaining screws.
3. The battery can now be removed by placing a screw driver into the slot (*slot indicated by arrow*) on the PCB and easing the battery free from its compartment.
4. Replace with a new CR2450 Lithium battery.



Reed Switch

Please Note: Not dependant on Polarity



Product Specifications


*Accuracy	+/- 0.5% of reading
Type	Oval Gear
Flow rate	1 – 30 L/m 0.26 – 8 US Gal/m
Maximum Pressure	6900k kPa 1000 PSI 69 Bar
Re-settable 'Batch' Total	99999.9
Non- Re-settable 'Total'	999999
Maximum Viscosity	1000 cP (Centipoise)
Maximum Temperature	55 Deg C / 131 Deg F
Minimum Temp	-14 Deg C / 6.8 Deg F

* When tested with lubrication oil @ 25°C. Allowances should be made for changes to these parameters.

Troubleshooting Guide


Problem	Cause	Remedy
Fluid will not flow through meter	a) Foreign matter blocking rotors b) Damaged rotors c) Meter connections over tightened d) Fluid is too viscous	a) Dismantle meter, clean rotors b) Replacement rotor assembly required. c) Re-adjust connections d) See specifications for maximum viscosity
Reduced flow through meter	a) Partially blocked b) Fluid is too viscous	a) Check and clean meter. b) See specifications for maximum viscosity
Meter reading inaccurate	a) Fluid flow rate is too high or too low b) Air in fluid. c) Excess wear.	a) See specifications for minimum and maximum flow rates b) Bleed air from system c) Check meter body and rotors. (see instructions)
Meter not giving a pulse signal	a) Faulty hall effect sensor b) Faulty reed switch c) Magnets failed	a) Replace PCB Board b) Replace PCB Board c) Replacement rotor assembly required
LCD register not working	a) Battery flat b) Faulty LC Display	a) Replace battery b) Replace PCB module

Exploded Diagram—Meter



Item No.	Part Description	Wetted Parts
1	Protective boot	
2	Electronic module retaining screws	
3	Electronic Module	
4	O-Ring	
5	Meter Body	CA313 Aluminium
6	Rotor Set	Acetal (Delrin)
7	O-Ring	Nitrile Butadiene Rubber
8	Meter Cap	CA313 Aluminium
9	Meter cap screws	

Spare Part Kit—Meter



Item No.	Part Description	Ordering codes
A	Electronics Kit	DKIT-IM012-LM
B	Meter Kit	MKIT-IM012-01

Meter Dimensions



Spare Part List—Control Handle and Extension

<i>Item No.</i>	<i>Part Description</i>	<i>Ordering codes</i>
1	Handle	JL125s
2	Adaptor—Handle to Meter	IM214s
3	Flexible Extension	JL3s

Note: No illustration of Handle, Adaptor or Flexible Extension

Warranty Information

Lubemate Warranty

1. Macnaught Pty Ltd (“Macnaught”) warrants that all products supplied by Macnaught under the “Lubemate” brand will be free from any defects caused by faulty materials or workmanship (“Warranty”) for a period of 12 months from the date of purchase of the product.
2. The warranty is conditional on the purchaser, during the Warranty period:
 - a. delivering to Macnaught a detailed notice setting out full details of any defect in any product and details of the date and place of purchase (together with copies of purchase receipts and/or other supporting documents); and
 - b. at the purchaser’s own cost, returning the defective product to Macnaught.
3. Subject to compliance by the purchaser with clause 2, Macnaught shall replace any product found defective by its inspection by reason of faulty materials or workmanship.
4. This Warranty does not cover the failure of products, parts or components which, in the sole judgment of Macnaught, arises other than from faulty materials or workmanship, including misuse, abrasion, corrosion, negligence, accident, unauthorised modification, improper use, storage or handling, faulty installation or tampering by the purchaser or any third party.
5. If Macnaught’s inspection discloses no defect in material or workmanship, the product will be returned to the purchaser at customary charges, which will be advised to the purchaser.
6. Macnaught’s liability and the purchaser’s rights under this Warranty shall be limited to the replacement of defective products and in particular, shall not extend to any direct, special, indirect or consequential damage or losses of any nature.
7. The foregoing Warranty supersedes, voids and is in lieu of all or any other warranties. This Warranty does not form part of, nor does it constitute, a contract between Macnaught and the end-user or purchaser. It is additional to any warranty given by the seller of the products. This Warranty does not exclude, limit, restrict or modify the non-excludable rights or remedies conferred upon the end-user or purchaser, or the non-excludable duties or liabilities imposed on the seller or Macnaught, by Part V, Divisions 2, 2A and Part VA of the Trade Practices Act 1974 (Commonwealth) or other legislative provisions. Macnaught otherwise excludes, to the extent permitted by law, any rights conferred on the end-user or purchaser or duties or liabilities imposed upon Macnaught.



Air Operated 3:1 Oil Ratio Pump

OP-31


Congratulations on purchase of this World Class Air Operated Oil Ratio Pump !

- World-class Industrial Oil Dispensing pumps with guaranteed performance & hassle free operation
- Pumps are designed to work in tough conditions & are ideal for use with medium to high viscosity oils (upto SAE 130) for transferring over short distances (upto 30 metres), mostly used with Trolley mounted kits
- All metal construction, fully CNC machined with hardened wear resistant moving parts
- Reciprocating piston operated 2-1/2" (63 mm) dia. Air Motor
- Available in three different sizes - Stub, 16 Gal & 55 Gal version
- Stub Pumps are supplied with Non Return Valve threaded 1" (F) for use on the bottom of the Suction Tube. Other pump lengths have a built in Strainer at pump inlet to keep contaminants away
- Pumps are single acting with discharge up to 14 LPM (3.70 GPM). Air Consumption: 230 LPM (61 GPM)


**Stub Version
OP/S/31B**



**16 Gal Version
OP/T2/31B**



**55 Gal Version
OP/T3/31B**



PUMP CONSTITUENTS

1. Pump Assembly
2. Bung Nut




Fig. 1


Contents

Page No.

PUMP CONSTITUENTS	1
PUMP CONSTRUCTION	3
GETTING STARTED	3
PUMP INSTALLATION & OPERATION	3
MAINTENANCE & REPAIR	4-8
• Air Motor Kit Replacement	5-8
EXPLODED VIEW	9
PARTS LIST	10-11
TROUBLESHOOTING	12
REPLACEMENT & SERVICE PARTS PROGRAM	13-14
• Replacement Parts Program	13
• Service Parts Program	14
SPECIFICATIONS	15
WARNINGS	15

PUMP CONSTRUCTION

Fig. 2



The pump is made up of two sections as below :-

- **DRIVE SECTION:-** It consists of an Air Motor Assembly driven by compressed air. The piston diameter of the air motor is 2.5" / 63 mm. The motor consists of an air cylinder with piston and one reciprocal valve with a nylon slider. The valve directs the compressed air alternately to the top or bottom of the piston, thus producing a reciprocating motion of the piston rod.
- **PUMPING SECTION:-** It consists of a pump in which a piston lifts media through Non Return Valves by reciprocating inside the suction tube. Media is discharged with pressure (from the outlet located at bottom of Air Motor) into the delivery hose / pipe.

NOTE

- **AIR MOTOR** of this pump starts automatically when the dispensing gun / tap is opened. When the dispensing gun / tap is closed, air motor builds up a back-pressure and stops operating the pumping section.
- **PRESSURE RATIO** of the pump states the ratio of the output fluid pressure to the incoming air pressure. When the pressure ratio is 3:1, we achieve an output media pressure up to 450 PSI (30 BAR) when the incoming air pressure is 150 PSI (10 BAR).

GETTING STARTED

Before installing the pump, make sure the following are available:

- **AIR SUPPLY:** An FRL (Filter-Regulator-Lubricator) unit must be used in the Air supply, before it is connected to the pump.
Set the regulator to 6 BAR (90 PSI) or any required inlet pressure, but never more than 150 PSI (10 BAR) or less than 30 PSI (2 BAR).
When not in use & at the end of each day, air supply to the pump must be switched off.
- **DISCHARGE HOSE:** It is recommended to use a hose with ½" I.D., with a Working Pressure of not less than 400 PSI (28 BAR). Burst Pressure must be atleast 1000 PSI (70 BAR) or more. Using a smaller I.D. hose will cause higher pressure loss.
- **DISPENSING GUN:** Based on the application, you may use a gun that is compatible with media being dispensed.
- **THREAD SEALANT:** Apply thread sealant on all threaded connections to ensure leak-proof operation.

PUMP INSTALLATION & OPERATION

1. Slide out the Bung from Suction Tube & screw it into the 2" opening on the drum.
2. Loosen the ring nut on Bung & carefully insert the pump Suction Tube through it. Once the Suction Tube touches the bottom of drum, tighten the ring nut.
3. Connect the appropriate hose and dispensing gun to the pump outlet. Use a thread sealant to avoid any leakage.
4. With the air supply turned off, connect the air line into the air inlet on the pump. Remove the vent plug on drum to create the required venting for pump operation.
5. Partially open the on/off air valve (It helps in creating initial vacuum when filling a totally dry pump). Pump will start operating automatically until it gets primed. Pump is said to be **Primed** when media is available at the pump outlet, making the pump ready to use. Once primed, the air motor will stop. Open the on/off air valve fully.
6. Operate the dispensing gun, which will actuate the air motor & pump will start dispensing.


MAINTENANCE & REPAIR

(Refer to Exploded View - Page 9)

General Precautions

- Before performing any service operation, always shut off the air supply and release the system pressure i.e. let the media out so that the pressure decreases. When storing the pump assembly out of the drum, cover the Filter Tube (60) with Filter Cap (61).
 - Be careful not to damage any parts when dismantling. While removing shafts which do not have key flats, use a Pipe wrench, Strap wrench or the like. The easiest way to remove such a shaft is to grip it in a vice with aluminium or copper jaws, clamp the shaft in a hand-drill chuck and then turn the chuck by hand.
 - Be careful when fitting O-rings and seals. Always lubricate them with oil before fitting. They must never be threaded over sharp edges when being fitted. Lubricate all moving parts with oil.
 - When troubleshooting, be on a lookout for dirt in valves / ball seats, scratches in sealing surfaces & damage in O-rings / seals / gaskets.
-

Recommended Tools



A Soft - Jaw vice
(Aluminum or Copper Jaws)



Threaded Pipe
1/2" (M)



Adjustable Caliper Wrench



Wide Jaw Plumbing Plier



Combination Wrench
Size 10, 13, 14, 21, 25 & 28 mm



Phillips Screwdriver



Adjustable C Hook Wrench
Size 1-1/4" to 3"



Tweezer



Soft Faced Plastic Mallet



Ball Pein Hammer



Pin Punch
Size 2 mm



Locking fluid

Air Motor Kit Replacement (Refer to Table 4 - Page 14)


1. Pull out Filter Cap (61) by hand. Hold Barrel (55) in a soft-jaw vice.



2. Tighten a 1/2" male threaded pipe into the outlet adapter (35) & unscrew Air Motor Assembly anticlockwise.



3. Pull Air Motor slightly to get access to Connector (47).



Connector


4. Support Extension Rod (48) on a V block & insert a pin punch vertically into the upper hole of Connector (47).



5. Tap lightly with a hammer to drive out upper Slotted Spring Pin (46) taking care not to bend Extension Rod (48).



6. Unscrew Connector (47) with wrench (size 14 mm) & separate Air Motor Assembly from Extension Rod (48).



7. Hold Barrel (55) in a soft-jaw vice. Attach an Adjustable C Hook Wrench (size 1-1/4" to 3") into the lug hole & Unscrew Coupler (44) anticlockwise.



Lug Hole

8. Remove Coupler (44).
Pull Extension Rod (48)
so that Piston (53) also
comes out of barrel (55).



9. Remove outlet adapter
(35) with wrench (size
28).



10. Unscrew Exhaust valve
(23) with a wide jaw plier.



11. Hold Air Motor Assembly
in a soft-jaw vice. Loosen
both Coupling Nuts (2)
using wrench (size 21
mm).



12. Remove Bend Pipe (1)
along with both Coupling
Nuts (2) & Sealing Rings
(3).



13. Unscrew both Bends (4)
using wrench (size 13
mm).



14. Lightly tap Cylinder (10)
with a plastic hammer &
unscrew it .




15. Unscrew Inlet Cover
Adapter (34) using wrench
(size 25 mm).



16. Connect a caliper wrench
into the holes on inlet
Cover (32) & unscrew it
anticlockwise.




17. Unscrew both Pushers (15) using wrench (size 25 mm).



18. Remove both Pushers (15), Springs (17), Pusher Nuts (18) & Pusher Buttons (19).



19. Using two wrenches (size 10 mm), hold Plunger Rod (9) & turn Connecting Rod (43) anticlockwise. This will unscrew Connecting Rod (43).



20. Remove Connecting Rod (43) along with Washer (42), Spring (41), Seal Support (40), Seals (39) & Slider Guide (38).




If Connecting Rod (43) is still attached to the inner rod of Slider (30), hold the inner rod in a vice & unscrew Connecting Rod (43) with wrench (size 10 mm).



21. Remove Slider (30) with a tweezer.



22. Open the two Screws (29) with a Philips screwdriver & remove Clip (28).



23. Remove Nylon Slider (27).



24. Remove Slider Guide (26).




25. Remove Seat (25) & Paper Seal (24). Clean the bottom surface thoroughly.




26. Replace the Air Motor Kit (KIT/T3/31B) as mentioned in Table 4 - Page 14, by following the steps 1-25 in reverse order taking care of the points below:

- Ensure all mating surfaces are clean before reassembly. Apply minor oil on all mating surfaces, O Rings & moving parts before reassembly.



Clean & apply oil

- Ensure that height of Nylon Slider (27) is approx. 5.3 - 5.7 mm. Also, hollow portion of Nylon Slider should rest evenly on top of Seat (25).




- When fitting Pushers (15), see through Inlet Cover (32) & ensure Pusher Buttons (19) are installed in centre position. Also ensure that Clip (28) is tight & Nylon Slider (27) moves smoothly.




- When fitting Plunger Rod (9) & Connecting Rod (43), apply locking fluid on the inner rod of Slider (30).



- Conical side of Seals (39) must face upwards. Assemble them with Slider guide (38), Seal Support (40) & mount them as a set on Connecting Rod (43).



- Lip of lower Seal (54) must face upwards, when mounted on Piston (53). Apply some oil on Seal before installation.



- While pushing Extension Rod (48) into Barrel (55), apply some oil on all parts & keep Slitted Washer (52) pressed evenly around Piston (53).




- While fitting Air Motor with Barrel (55), apply locking fluid on Barrel threads. TIGHTEN WITH HAND to avoid overtightening. DO NOT tighten with any tool otherwise Seal (45) may get damaged.



EXPLODED VIEW

Fig. 3



PARTS LIST**Table 1**

REFERENCE NO. FROM EXPLODED VIEW	DESCRIPTION	QUANTITY
1	Bend Pipe	1
2	Coupling Nut	2
3	Sealing Ring	2
4	Bend	2
5	Cylinder Cover	1
6	O Ring BS141	2
7	Plunger Nut	1
8	Rubber Plunger	1
9	Plunger Rod	1
10	Cylinder	1
11	O Ring BS614	2
12	Rod Guide	1
13	O Ring	1
14	Housing	1
15	Pusher	1
16	O Ring BS617	4
17	Pusher Spring	2
18	Pusher Nut	2
19	Pusher Button	2
20	Circlip	1
21	Filter (B)	2
22	O Ring BS121	2
23	Exhaust Valve	1
24	Paper Seal	1
25	Seat	1
26	Slider Guide	1
27	Nylon slider	1
28	Clip	1
29	Self Tapping Screw	2
30	Slider	1
31	O Ring BS129	1
32	Inlet Cover	1
33	Filter (B)	1
34	Air Inlet Adapter	1
35	Outlet Adapter	1
36	Adapter Cap	1
37	O Ring BS115	1
38	Slider Guide	1
39	Seal	4
40	Seal Support	1
41	Spring	1
42	Washer	1
43	Connecting Rod	1
44	Coupler	1

REFERENCE NO. FROM EXPLODED VIEW	DESCRIPTION	QUANTITY
45	Washer	1
46	Slotted Spring Pin (Upper)	2
47	Connector	1
48	Extension Rod	1
49	Slotted Spring Pin (Lower)	1
50	Piston Coupler	1
51	Ball (5/8")	1
52	Slitted Washer	1
53	Piston	1
54	Seal	1
55	Barrel	1
56	Bung	1
57	Circlip	1
58	Ball (7/8")	1
59	O Ring BS126	1
60	Filter Tube	1
61	Filter Cap	1

TROUBLESHOOTING
(Refer to Exploded View - Page 9)

Table 2

PROBLEM	POSSIBLE CAUSE	SOLUTION
Pump operates, but does not dispense media at all	Media viscosity is too high	Make sure that media used has a viscosity of SAE 130 or lower
	Drum is Empty	Media level inside the drum may be too low. Refill drum
	Pump inlet is blocked	Remove suction tube & clean strainer at pump inlet
	Air Inlet Pressure is too less	Increase air pressure. It must be at least 30 PSI (2 BAR)
Pump not working / less discharge	Air Inlet pressure is too less	Increase air pressure. It must be at least 30 PSI (2 BAR)
	Nylon Slider (27) is jammed / overtight	<ol style="list-style-type: none"> 1. Check for any build-up edge on Clip (28) & tighten it again. Make sure the movement of Nylon Slider (27) is neither very loose nor very tight 2. If needed, replace Nylon Slider (27). Also replace the Paper Seal (24), Seat (25) & Slider Guide (26) to ensure the best fitting
Pump not working / less discharge	Plunger (9) / Connecting Rod (43) / Piston (53) jammed.	<ol style="list-style-type: none"> 1. Remove suction tube. Disconnect Air Motor Assembly from Pumping Section by removing the upper Slotted Spring Pin (46) from Connector (47) 2. Supply input air to Air Motor. If it works properly without the barrel assembly, then the problem lies with the pumping section. Otherwise check the Air Motor for smooth movement 3. After locating the faulty section, check the respective Piston / Plunger & the associated washers & seals for any overlap or wear & tear. Replace the defective parts from Repair Kit 4. Ensure to replace the moving parts having close tolerances (such as Nylon Slider (27) & Seat (25) as a SET to ensure the best fitting
		<ol style="list-style-type: none"> 1. Remove suction tube. Disconnect Air Motor Assembly from Pumping Section by removing the upper Slotted Spring Pin (46) from Connector (47) 2. Supply input air to Air Motor. If it works properly without the barrel assembly, then the problem lies with the pumping section. Otherwise check the Air Motor for smooth movement 3. After locating the faulty section, check the respective Piston / Plunger & the associated washers & seals for any overlap or wear & tear. Replace the defective parts from Repair Kit 4. Ensure to replace the moving parts having close tolerances (such as Nylon Slider (27) & Seat (25) as a SET to ensure the best fitting
Pump continues to operate even after the trigger of dispensing gun has been released	Leakage in the assembly	Check all the connections to ensure they are air tight. Use thread sealant. Check O rings & seals for damage. Replace the defective parts from Repair Kit
Media comes through the air Exhaust Valve (23)	Media leaks into the Air Motor	Check Slider Guide (38), O Rings (11) & (37), Seals (39) & Seal Support (40) for wear & tear. Replace the damaged parts from Repair Kit
Air passes directly from inlet to the outlet & pump does not work	Nylon Slider (27) is jammed / overtight	<ol style="list-style-type: none"> 1. Check for any build-up edge on Clip (28) & tighten it again. Make sure the movement of Nylon Slider (27) is neither very loose nor very tight 2. If needed, replace Nylon Slider (27). Also replace the Paper Seal (24), Seat (25) & Slider Guide (26) to ensure the best fitting
Discharge suddenly stopped while the pump was running	Seals / O Rings Damage	Check all seals / O Rings & replace the damaged parts from Repair Kit
	Chip / Other foreign particles get clogged at dispensing gun / discharge outlet	Clean all foreign particles / chips
	Clogging of Filter Tube (60)	Open Filter Tube (60), clean it & reassemble it properly

REPLACEMENT & SERVICE PARTS PROGRAM
(Refer to Exploded View - Page 9)

Table 3

REPLACEMENT PARTS PROGRAM

REFERENCE NO. FROM EXPLODED VIEW	PART NO.	DESCRIPTION	QUANTITY
56	BUNG/OP/42	Bung	1

SERVICE PARTS PROGRAM




Fig. 4




Fig. 5




Fig. 6

Table 4

KIT PART NO.	KIT DESCRIPTION	CONSTITUENT PART NO.	PART DESCRIPTION	REFERENCE NO.	QUANTITY PER KIT
KIT/T3/31B	AIR MOTOR KIT	BEND/90/RP	Bend	4	2
		ORG/BS141	O Ring	6	2
		ORG/BS614	O Ring	11	1
		ORG/BS617	O Ring	16	4
		ORG/BS121	O Ring	22	2
		SEL/P/RP	Paper Seal	24	1
		SET/RP	Seat	25	1
		SLD/NY/RP	Nylon Slider	27	1
		ORG/BS115	O Ring	37	1
		GUD/SEL/RP	Slider Guide	38	1
		SEAL/RP	Seal	39	4
		SU/SEL/RP	Seal Support	40	1
		ROD/CNR/S/RP	Connecting Rod	43	1
		WSR/PVC/RP	Washer	45	1
		SSP/3/0.6/15.3	Slotted Spring Pin	46	1
		WSR/TU/RP	Slitted Washer (Turcite)	52	1
		OS/RP	Seal	54	1
ORG/BS126	O Ring	59	1		

SPECIFICATIONS*

Table 5

Flow Rate	Up to 14 LPM (3.70 GPM)
Working Pressure	2-10 BAR (30-150 PSI)
Maximum Air Inlet Pressure	10 BAR (150 PSI)
Maximum Media Outlet Pressure	30 BAR (450 PSI)
Air Inlet Connection	1/4" (F)
Pump Inlet on Stub Pumps only	1" (F)
Pump Outlet Connection	1/2" (F)
Air Consumption	230 LPM (61 GPM)
Noise Level	81 db

* Pump is available in three different sizes - Stub, 16 Gal & 55 Gal version

WARNING

- Always wear protection gear like safety goggles, gloves, apron, and ear plugs while operating the pump
- Never let any body part come in front of, or in contact with the control outlet
- Always cut off air supply after use, so that media cannot leak in case any of the pump component fails
- Before switching the air supply on, check hoses for any sign of wear, leak or loose fittings. Replace as necessary
- Do not smoke near the pump. Do not use the pump near a source of spark / open flames
- When changing the working fluid, at least 1 litre of new fluid should be discarded to avoid mixing of fluids
- Pump should NOT be operated for more than 4 hrs continuously
- Pump must be supplied with CLEAN & DRY compressed air via an FRL unit
- Before attempting any maintenance or repair of this product, disconnect air supply and then operate dispensing gun to release fluid pressure
- Use only genuine factory parts for repair

WETTED COMPONENTS

Steel, Brass, Aluminum, Hi Nitrile Rubber, Polyurethane, Turcite

RECOMMENDED USE

ATF, Engine Oil, Gear Oil, Hydraulic Oil, Medium to high viscosity oils (up to SAE 130), Diesel, Kerosene

DO NOT USE WITH

Corrosive Fluids, Solvents, Acid, Alkalis, Antifreeze, waste oil or any other media not compatible with the pump components

