

PULSE 200



INSTRUCTION MANUAL

BOSSWELD

MACHINE OVERVIEW

1. Control Panel
2. MIG Torch Euro Connector
3. Polarity Switching Cable
4. Aero Socket for Spool Gun
5. Positive Output Connection Socket
6. Negative Output Connection Socket

7. Gas Inlet Connector
8. Input Power Cable
9. Power Switch



CONTROL PANEL OVERVIEW



1. Left Knob: to adjust welding voltage
2. HOME Button: to select DC MIG / PULSE MIG / DOUBLE PULSE MIG / MMA / Lift TIG
press 2 times HOME button: to select gas types / Spool Gun
3. Right Knob: to adjust WELD PARAM button's functions
4. WELD PARAM Button: to select Inductance / Wire Dia. / 2T/4T / Waves / Pulse...

CONTENTS


Machine Overview	Page 02
Control Panel Overview	Page 02
Specifications	Page 03
Wire Feeder Overview	Page 04
Safety Information	Page 04
Machine Safety	Page 05
Work Area Safety	Page 05
Personal Protective Equipment (PPE)	Page 06
Maintenance	Page 06
MIG Set Up - Teflon Liner	Page 07
MIG Set Up - Steel Liner	Page 08
MIG Set Up - Wire Feeder	Page 09
MIG Gasless Machine Set Up	Page 10
MIG Gas Machine Set Up	Page 11
MIG Operation	Page 12
MMA (Stick) Machine Set Up	Page 13
MMA (Stick) Operation	Page 14
TIG Welding Machine Set Up	Page 15
TIG (Lift Start) Operation	Page 16
Trouble Shooting - Wire Feeder	Page 17
Error Code Warning! & Operation	Page 17
Disposal	Page 17
BZ24 Torch & Spare Parts	Page 18
SPX15 Spool Gun & Spare Parts	Page 19
Box Contents	Page 19
Warranty Information	Page 20

SPECIFICATIONS

Primary Input Power	1 Phase 240V 50-60 HZ +/-10%		
Duty Cycle @ 40°C 10min	15%@200A 60%@100A 100%@77A	15%@200A 60%@100A 100%@100A	15%@200A 60%@100A 100%@77A
Function	MIG	Lift TIG	MMA
Welding Current Range (A)	30 – 200	10 – 200	10 – 200
I Max (A)	38	18	41
I eff (A)	15	15	15
Wire Diameter Range	0.8 – 1.2mm		
Electrode Diameter Range	2.5 – 5.0mm		
Protection	IP21S		
Insulation Class	H		
Thermal Overload	Yes		
Dimensions / Weight	L495 x W210 x H330 mm		
Weight	12 kg		
Part Number	633200		

WIRE FEEDER OVERVIEW

1. Spool Holder - 1kg / 5kg
2. Wire Inlet
3. Wire Drive Roller
4. Wire Feed Tension Arm
5. Wire Feed Tension Adjustment Latch
6. Wire Check Button
7. Gas Check Button



SAFETY INFORMATION



WARNING! The device and packaging material are not toys! Children must not be allowed to play with the machine and its accessories. Plastic parts and packaging are choking risks for children.

- Open the packaging and remove the welder carefully.
- Check that the delivery is complete.
- If possible, store the packaging until the warranty period has expired.

The user of this welder is responsible for their own safety and the safety of others. It is important to read, understand and respect the contents of this user guide. When using this welder, basic safety precautions, including those in the following sections must be followed to reduce the risk of fire, electric shock and personal injury. Ensure that you have read and understood all of these instructions before using this welder.

Persons who are not familiar with this user guide should not use this welder. Keep this booklet in a safe place for future reference.

TRAINING

The operator should be properly trained to use the welding machine safely and should be informed about the risks relating to arc welding procedures. This user guide does not attempt to cover welding technique. Training should be sought from qualified / experienced personnel on this aspect, especially for any welds requiring a high level of integrity for safety.

SERIOUS FIRE RISK

The welding process produces sparks, droplets of fused metal, metal projectiles and fumes. This constitutes a serious fire risk. Ensure that the area in which welding will be undertaken is clear of all inflammable materials. It is also advisable to have a fire extinguisher, and a welding blanket on hand to protect work surfaces.

MACHINE SAFETY

Keep the welding cables, work clamp and electrode holder in good condition. Failure to do this can result in poor welding quality, which could be dangerous in structural situations.

Prior to use, check for breakage of parts and any other conditions that may affect operation of the welder. Any part of the welder that is damaged should be carefully checked to determine whether it will perform its intended function whilst being safe for the operator. Any part that is damaged should be properly repaired, or replaced by an authorised service centre.

IMPROPER USE

It is hazardous to use the welding machine for any work other than that for which it was designed e.g. do not use welder for thawing pipes.

HANDLING

Ensure the handle is correctly fitted. As welding machines can be heavy, always use safe lifting practices when lifting.

POSITION AND HANDLING

To reduce risk of the machine being unstable / danger of overturning, position the welding machine on a horizontal surface that is able to support the machine weight. Operators **MUST NOT BE ALLOWED** to weld in raised positions unless safety platforms are used.

WORK AREA SAFETY

- Ensure a clear, well lit work area with unrestricted movement for the operator.
- The work area should be well ventilated, as welding emits fumes which can be dangerous.
- Always maintain easy access to the ON/OFF switch of the welder, and the electrical mains supply
- Do not expose the welder to rain and do not operate in damp or wet locations

Where welding must be undertaken in environments with increased risk of electric shock, confined spaces or in the presence of flammable or explosive materials, it is important that the environment be evaluated in advance by an "expert supervisor". It is also recommended that welding in these circumstances be carried out in the presence of persons trained to intervene in emergencies.

AVOID ELECTRICAL CONTACT

Use adequate electrical insulation with regard to the electrode, the work piece and any accessible earthed metal parts in the vicinity. Avoid direct contact with the welding circuit. The no load voltage between the work clamp and the electrode can be dangerous under certain circumstances.

Note: For additional protection from electric shock. It is recommended that this welder be used in conjunction with a residual current device (RCD) with rated residual current of 30mA or less.

In general the use of extension leads should be avoided. If used however, ensure that the extension lead used with the welder is of a suitable current rating and heavy duty in nature that **MUST** have an earth connection. If using the welder outdoors, ensure that the extension lead is suitable for outdoor use. Always keep extension leads away from the welding zone, moisture and any hot materials.

WELDING SURFACES

- Do not weld containers or pipes that hold, or have held, flammable liquids or combustible gases or pressure.
- Do not weld on coated, painted or varnished surfaces as the coatings may ignite, or can give off dangerous fumes.

WORK PIECE

When welding, the work piece will remain at high temperature for a relatively long period. The operator must not touch the weld or the work piece unless wearing welding gloves. Always use pliers or tongs. Never touch the welded material with bare hands until it has completely cooled

VOLTAGE BETWEEN ELECTRODE HOLDERS OR TORCHES

Working with more than one welding machine on a single work piece, or on work pieces that are connected, may generate a dangerous accumulation of no-load voltage between two different electrode holders or torches, the value of which may reach double the allowed limit.

PERSONAL PROTECTION EQUIPMENT (PPE)

PERSONAL PROTECTIVE EQUIPMENT MUST BE USED WHEN MACHINE IS IN USE!

GLOVES AND PROTECTIVE CLOTHING

Use protective gloves and fire resistant protective clothing when welding. Avoid exposing skin to ultraviolet rays produced by the arc.

WELDING HELMET

Under no circumstances should the welder be operated unless the operator is wearing a welding helmet to protect the eyes and face. There is serious risk of eye damage if a helmet is not used. The sparks and metal projectiles can cause serious damage to the eyes and face. The light radiation produced by the arc can cause damage to eyesight, and burns to skin. **Never remove the welding helmet whilst welding.**

SAFETY GLASSES

Always use appropriate safety glasses when brushing, chipping or grinding the slag from the weld.

OTHER PERSONS

Ensure that other persons are screened from the welding arc and are at least 15 metres away from the work piece. Always ensure that the welding arc is screened from onlookers. Use screens if necessary or non-reflecting welding curtain. Do not allow children or animals access to the welding equipment or to the work area.

SWITCHING OFF

When the operator has finished welding they must switch the welder off. DO NOT put the electrode holder down with the welder switched ON. When leaving the welder unattended, switch OFF and disconnect the welder from the electrical mains supply. Do not leave hot material unattended after welding.

FUMES & GASES ARE DANGEROUS

Smoke and gas generated whilst welding or cutting can be harmful to people's health. Welding produces fumes and gases. Breathing these fumes and gases can be hazardous to your health.

- Do not breathe the smoke and gas generated whilst welding or cutting, keep your head out of the fumes
- Keep the working area well ventilated, use fume extraction or ventilation to remove fumes and gases
- In confined or heavy fume environments always wear an approved air-supplied respirator. Welding fumes and gases can displace air and lower the oxygen level causing injury or death. Be sure the breathing air is safe.
- Do not weld in locations near de-greasing, cleaning, or spraying operations. The heat and rays of the arc can react with vapours to form highly toxic and irritating gases.
- Materials such as galvanized, lead, or cadmium plated steel, containing elements that can give off toxic fumes when welded. Do not weld these materials unless the area is very well ventilated, and or wearing an air supplied respirator.

MAINTENANCE

WARNING! Before starting any cleaning, or maintenance procedures on the welding machine, make sure that it is switched OFF and disconnected from the mains supply.

There are no user serviceable parts inside the welder. Refer to a qualified service personnel if any internal maintenance is required. After use, wipe the welder down with a clean soft dry cloth.

Regular inspection of the supply cord is required. If damaged is suspected, must be immediately replaced by the manufacturer, its service agent or similarly qualified persons.

STORAGE / TRANSPORT

Store the welder and accessories out of children's reach in a dry place. If possible store the welder in the original packaging. The appliance must be secured against falling or rolling over during transport.





MIG SET UP - TEFLON LINER

WARNING! Ensure the machine is turned off and disconnected from the power supply before performing any of the following operations.



FITTING TEFLON LINER (BLACK)

1. Lay the MIG torch out straight and flat on the ground and remove the nozzle, contact tip, tip holder and gas diffuser.
2. Remove the liner retaining nut from the euro torch end to install liner into the torch lead all the way out the end of the torch then reinstall retaining nut back and use spanner to tighten it.
3. Reinstall back the gas diffuser, tip holder and contact tip. Do not over tighten, or you may damage the tip holder.
4. Open side door of the machine. Release the Wire Feed Tension Adjustment Knob by pulling it outwards.
5. Install Euro connect MIG torch over the protruding wire, line up and screw the Euro connector nut up firmly. Use knife to make a mark on the teflon liner.
6. Uninstall the MIG torch to knife cut the teflon liner 45° top and bottom (> Cut). Reinstall MIG torch.





MIG SET UP - STEEL LINER

WARNING! Ensure the machine is turned off and disconnected from the power supply before performing any of the following operations.



FITTING STEEL LINER (RED)

1. Lay the MIG torch out straight and flat on the ground and remove the nozzle, contact tip, tip holder and gas diffuser.
2. Remove the liner retaining nut from the euro torch end to install liner into the torch lead all the way out the end of the torch then reinstall retaining nut back and use spanner to tighten it.
3. Snip the Steel liner 3mm past the end of the torch neck. Reinstall back the gas diffuser, tip holder and contact tip.
4. Open side door of the machine. Release the Wire Feed Tension Adjustment Knob by pulling it outwards.
5. Place Guide Tube from Euro Connection Terminal
6. Install MIG Torch and screw up firmly to position the Guide Tube.
7. Use allen key to lock Guide Tube.



MIG SET UP - WIRE FEEDER

WARNING! Ensure the machine is turned off and disconnected from the power supply before performing any of the following operations.



FITTING WIRE SPOOL

1. Remove spool hub nut and place a 5kg (D200) spool of wire on spool hub. For 1kg (D100) spool, remove spool hub.
2. Reinstall spool retaining nut and tighten. Do not overtighten.
3. Make sure the spool can rotate smoothly.




THREADING AND TENSIONING WIRE

4. Check drive roller is matched to the wire size used.
U Groove = Aluminium
V Groove = Steel
Knurled Groove = Flux Cored Wire / Gasless Flux Cored Wire
5. Carefully feed wire through the inlet guide tube on to the drive roller and into the outlet guide tube until it passes through the inlet tube, and into the torch.
Note: Hold wire to prevent the spool uncoiling.
6. Close the Wire Feed Tension Arm. Replace Wire Feed Tension Adjustment Knob and tighten. Do not overtighten.



SET UP MIG TORCH

7. Plug the machine 15Amp input power lead into the wall socket, and switch to ON position.
8. Press and hold the trigger on the MIG Torch. This will feed the wire through the torch. Release trigger when wire appears at the end of the torch.
9. Switch machine power OFF.
10. Reinstall the welding tip over wire. Ensure contact tip size matches the size of the wire being used. Do not overtighten. Reinstall nozzle.
11. Trim wire to the end of the nozzle.




MIG WELDING MACHINE SET UP - GASLESS

WARNING! Ensure the machine is turned off and disconnected from the power supply before performing any of the following operations.

Connecting MIG Torch, Earth Clamp & Setting Polarity



1. Plug **MIG Torch** into the Euro Connection terminal.
2. Plug **Earth Clamp** connector into the Positive terminal. Twist to ensure a good connection.
3. Plug **Polarity** Change Power Connection into the Negative terminal and tighten.



SETTING MACHINE POLARITY

DCEN - GASLESS

DCEP - GAS



Welding Setup

3. Connect the earth clamp firmly to the work-piece ensuring that the clamp makes good contact with bare metal.
4. Plug the machine 15Amp input power lead into the wall socket. Turn the power outlet **ON** and turn on the machine using the power switch on the rear of the machine.
5. Press **HOME** button then press the left knob to select modes: DC MIG, DC MIG SPOOL GUN.
6. Continues to use left knob to select GASLESS modes: DC MIG Constant Voltage, DC MIG FLUX CORED and DC MIG SPOOL GUN.
7. Rotate left knob to adjust welding voltage. Rotate right knob to adjust welding current.
8. Press **WELD PRAM** button to adjust functions: Inductance, Wire Diameter, 2T/4T, Post-flow Time, Slow wire-feeding



OPTIONAL ACCESSORIES



Spool Gun

4Mt: 97.SPX15.4.2


8Mt: 97.SPX15.8.2

MIG WELDING MACHINE SET UP - GAS

WARNING! Ensure the machine is turned off and disconnected from the power supply before performing any of the following operations.


Connecting MIG Torch, Earth Clamp & Setting Polarity

1. Plug **MIG Torch** into the Euro Connection terminal.
2. Plug **Earth Clamp** connector into the Negative terminal.
Twist to ensure a good connection.
3. Plug **Polarity** Change Power Connection into the Positive terminal and tighten.



Connecting Gas

4. Connect the gas line to the regulator on the gas bottle.
Note: CHECK FOR LEAKS prior to welding
5. Connect the Gas line to the machine Inlet Gas Connector on the rear panel



Welding Setup

6. Connect the work clamp firmly to the work-piece ensuring that the clamp makes good contact with bare metal.
7. Plug the machine 15Amp input power lead into the wall socket.
Turn the power outlet **ON** and turn on the machine using the power switch on the rear of the machine.
8. Carefully open the valve of the gas cylinder. Adjust to required gas flow rate as indicated on the regulator. As a guide, start with a gas flow rate of 12-15L/min
9. Press **HOME** button then press the left knob to select modes: DC MIG Constant Voltage DC MIG, PULSE MIG, DOUBLE PULSE MIG and DC MIG SPOOL GUN.
10. Continues to use left knob to select GAS modes.
11. Press **WELD PRAM** button to adjust functions: Inductance, Wire Diameter, 2T/4T, Post-flow Time, Slow wire-feeding



WELDING GAS SELECTION GUIDE

Use the table below as a guide:

METAL TYPE	RECOMMENDED GAS
Mild Steel	Ar-CO ²
Stainless Steel	Ar-CO ₂ -O ²
Low Alloy Steel	Ar-CO ²
Galvanised Steel	Ar-CO ²
Aluminium	Ar



OPERATION - MIG WELDING

WARNING! Ensure appropriate PPE is worn, and work area is clear of hazards prior to operation.

Starting The Arc

1. Feed approximately 8-10mm of wire from the end of the torch (also called 'stickout') by pulling the trigger on the torch.
Note: The shorter the stickout, the hotter the weld will be.
2. Touch the MIG wire to the work piece and raise it again approximately 1-2mm above the work piece.
3. Pull the trigger on the MIG torch, gas will flow and the wire will start to feed. When the wire touches the work piece the arc will strike and the wire will melt.

Forhand Pushing Technique

1. Hold the MIG torch at an angle of approximately 10°
Note: Different angles will result in different weld bead shapes
2. Pull the trigger and slowly push the MIG torch away from you in the direction you wish to weld, ensuring the wire is pointing forward towards the leading edge of the weld.

Backhand/Pulling Technique

1. Hold the MIG torch at an angle of approximately 10°
Note: Different angles will result in different weld bead shapes
2. Pull the trigger and slowly pull the MIG torch towards you in the direction you wish to weld, ensuring you keep the wire at the edge of the weld puddle.

STICK WELDING SET UP

WARNING! Ensure the machine is turned off and disconnected from the power supply before performing any of the following operations.

Fitting the Arc and Work Clamp

1. For the most common applications, plug the **Earth Clamp** connector into the Negative terminal. Twist to ensure a good connection.
2. Plug the **Electrode Holder** connector into the Positive terminal. Twist to ensure a good connection.



Grounding and Fitting the Electrode

3. Take the electrode holder and press the handle to open the tong. Insert the bare metal rod end of the electrode and release the handle to clamp the electrode.
4. Connect the earth clamp firmly to the work-piece ensuring that the clamp makes good contact with bare metal.



Welding Setup

5. Plug the machine 15Amp input power lead into the wall socket. Turn the power outlet **ON** and turn on the machine using the power switch on the rear of the machine. **WARNING:** Ensure the electrode/electrode holder is not near the work-piece when switching on the machine.
6. Press **HOME** button then press the left knob to select MMA.
7. Rotate left knob to adjust welding current. Rotate right knob to adjust welding voltage.
8. Press **WELD PRAM** button to adjust functions: Hot Start, Arc Force and VRD.



MMA (STICK) WELDING OPERATION

WARNING! Ensure appropriate PPE is worn, and work area is clear of hazards prior to operation.

Starting The Arc

1. Hold the Electrode above the work piece. In a smooth, quick motion, scratch the electrode across the work piece to create the arc.

Welding Work Piece

2. Hold the Electrode slightly above the work piece to maintain the arc, moving the electrode at an even speed to create an even weld distribution.

Finishing the Weld

3. Pull the electrode away from work piece quickly to break the arc.
4. Once the weld has cooled, clean the weld by chipping away at slag to reveal the weld metal.

ELECTRODE SELECTION GUIDE

Electrode size selection will be determined by the thickness of the section being welded. Use the table below as a guide:

AVERAGE METAL THICKNESS	ELECTRODE SIZE
1.0 - 2.0mm	2.0mm
2.0 - 5.0mm	2.6mm
5.0 - 8.0mm	3.2mm
8.0+	4.0mm

WELDING CURRENT GUIDE

Welding current level is determined by the size of electrode. Use the table below as a guide:


ELECTRODE SIZE/GAUGE	WELDING CURRENT
1.6mm	40 - 50 Amps
2.0mm	50 - 75 Amps
2.5mm	75 - 105 Amps
3.2mm	105 - 140 Amps
4.0mm	140 - 160 Amps

TIG WELDING MACHINE SET UP

WARNING! Ensure the machine is turned off and disconnected from the power supply before performing any of the following operations.


Fitting the TIG Torch, Earth Clamp & Gas Leads

1. Plug **Earth Clamp** connector into the **Positive** terminal.
Twist to ensure a good connection.
2. Plug **TIG Torch** into the **Negative** terminal. Twist to ensure a good connection.
3. Connect gas line to regulator on gas bottle.
Note: CHECK FOR LEAKS prior to welding



Welding Setup

4. Connect the work clamp firmly to the work-piece ensuring that the clamp makes good contact with bare metal.
5. Plug the machine 15Amp input power lead into the wall socket. Turn the power outlet **ON** and turn on the machine using the power switch on the rear of the machine.
6. Carefully open the valve of the gas cylinder. Adjust to required gas flow rate as indicated on the regulator.
7. Press **HOME** button then press the left knob to select TIG.
8. Rotate right knob to adjust welding current.



WELDING GAS SELECTION GUIDE

Use the table below as a guide:

METAL TYPE	RECOMMENDED GAS
Mild Steel	Ar
Stainless Steel	Ar
Low Alloy Steel	Ar
Galvanised Steel	Ar



OPTIONAL ACCESSORIES



Bossweld Argon
Flowmeter Regulator
400209



9 Series TIG Torch
with Valve 4m
95.9FV.4.1.DA25

TIG WELDING OPERATION (LIFT START)

WARNING! Ensure appropriate PPE is worn, and work area is clear of hazards prior to operation.

Starting The Arc

1. Lay the outside edge of the Gas Cup on the work piece. Maintain a 1-3mm gap between the Tungsten Electrode and the work piece.
2. Rock the torch sideways so the Tungsten Electrode touches the work piece and hold momentarily.
3. Rock the torch back, the arc will ignite as the Tungsten Electrode lifts off the work piece.
4. Lift the torch and hold approximately 2mm above the work piece to maintain the arc.



Welding Work Piece

5. Hold the Torch in place, moving in a small circular motion, until a weld pool is generated.
6. Tilt the torch at a 75° angle, introducing the filler wire (TIG rod) into the leading edge of the weld pool at a 15° angle.
7. Move Torch and filler wire smoothly and at an even speed to create an even weld distribution. The arc will melt the filler wire into the pool as the torch moves forward.

Note: It is important to keep the molten end of the filler wire inside the gas shield to protect from oxidation and contamination.



Finishing the Weld

8. Pull electrode away from work piece quickly to break the arc.



TROUBLE SHOOTING

PROBLEM	SUGGESTED REMEDY
No wire feed	1. Check that the MMA/MIG selector switch set to MIG position
Inconsistent / interrupted wire feed	<ol style="list-style-type: none"> 1. Be sure to adjust the wire feed and voltage dials for MIG welding. The current dial is for MMA welding mode. 2. Select the correct polarity for the wire being used. 3. Incorrect wire speed: adjust the wire feed speed 4. Incorrect voltage: adjust the voltage setting 5. MIG Torch kinked: remove the kink, reduce the angle or bend 6. Tip worn/incorrect: replace the tip with correct size and type 7. Liner worn/clogged/incorrect size: try to clear the liner by blowing out with compressed air as a temporary cure, it is recommended to replace the liner regularly. Install the correct size liner. 8. Blocked/worn inlet guide: clear or replace the inlet guide tube 9. Misaligned in drive roller groove: reposition the wire into the groove of the drive roller 10. Incorrect/worn drive roller: fit the correct size/type drive roller. Replace drive roller 11. Drive roller pressure too high: reduce the drive roller pressure. 12. Tension high on wire spool hub: reduce the spool hub brake tension 13: Wire tangled/crossed: remove the spool untangle the wire or replace the wire. 14. Contaminated MIG wire: use clean dry rust free wire. Do not lubricate the wire with oil, grease etc.
Shutdown procedure	The machine has a 15 second power off delay for shutdown.

ERROR CODE WARNING! & OPERATION

OVER TEMPERATURE!

When welder operates at full load maximum current for a long time, a OVER TEMPERATURE will appear. This means that the temperature inside the machine has exceeded the standard temperature. Please stop welding immediately, but do not turn off the power and let the fan continue to operate and let the welder cooling. Welding can be resumed after the welding temperature drops below the standard temperature and there is no warning display of OVER TEMPERATURE.

OVER CURRENT!

When the IGBT current exceeds the safety value when the welding machine is running, the welding machine will enter the OVER CURRENT protection to prevent the damage of IGBT. Please stop welding immediately, turn off the welder for 10-30s and then restart it. If the OVER CURRENT warning still appear, need to be repaired by professional maintenance personnel.

DISPOSAL

DISPOSING OF THE PACKAGING

Recycling packaging reduces the need for landfill and raw materials. Reuse of the recycled material decreases pollution in the environment. Please recycle packaging where facilities exist. Check with your local council authority for recycling advice.

DISPOSING OF THE WELDER

Welders that are no longer usable should not be disposed of with household waste but in an environmentally friendly way. Please recycle where facilities exist. Check with your local council authority for recycling advice.

BZ24 BINZEL STYLE TORCH & SPARE PARTS

BZ24 TORCH SPARES PACK

P/N: 92.24FEK

1 x BZ24 conical nozzle
1 x BZ24 M6 tip holder
1 x BZ24 gas diffuser
3 x 0.9mm M6 contact tips, 3x HD
3 x 1.2mm M6 contact tips, 3x HD



Part No.	Description
92.ER.24.3	Binzel Style BZ24 Complete MIG Torch Ergon 3Mt
92.ER.24.4	Binzel Style BZ24 Complete MIG Torch Ergon 4Mt
92.ER.24.5	Binzel Style BZ24 Complete MIG Torch Ergon 5Mt
92.02.24.10	ø 10mm Adjustable Tapered Nozzle
92.02.24.CO	ø 12.5mm Adjustable Conical Nozzle
92.02.24.CL	ø 17mm Adjustable Cylindrical Nozzle
92.01.15.06	Contact Tip 0.6mm x M6 x 6mm dia x 25mm long
92.01.15.08	Contact Tip 0.8mm x M6 x 6mm dia x 25mm long
92.01.15.09	Contact Tip 0.9mm x M6 x 6mm dia x 25mm long
92.01.15.10	Contact Tip 1.0mm x M6 x 6mm dia x 25mm long
92.01.25.06	Contact Tip Heavy Duty 0.6mm x M6 x 8mm dia x 25mm long
92.01.25.08	Contact Tip Heavy Duty 0.8mm x M6 x 8mm dia x 25mm long
92.01.25.09	Contact Tip Heavy Duty 0.9mm x M6 x 8mm dia x 25mm long
92.01.25.10	Contact Tip Heavy Duty 1.0mm x M6 x 8mm dia x 25mm long
92.01.25.12	Contact Tip Heavy Duty 1.2mm x M6 x 8mm dia x 25mm long
92.01.25.14	Contact Tip Heavy Duty 1.4mm x M6 x 8mm dia x 25mm long
92.01.25.16	Contact Tip Heavy Duty 1.6mm x M6 x 8mm dia x 25mm long
92.01.M6A09	Contact Tip 0.9mm x M6 Aluminium x 8mm dia x 28mm long
92.01.M6A10	Contact Tip 1.0mm x M6 Aluminium x 8mm dia x 28mm long
92.01.M6A12	Contact Tip 1.2mm x M6 Aluminium x 8mm dia x 28mm long
92.05.24R	Gas Diffuser - Red Rubber
92.05.24	Gas Diffuser - Ceramic
92.05.24.M6	Tip Holder M6
92.06.24	Swan Neck
92.09.HANDLE	Ergonomic handle with screws
92.09.BWT	Trigger
92.04.B3	Blue Steel Liner 0.6–0.8mm 3Mt
92.04.B4	Blue Steel Liner 0.6–0.8mm 4Mt
92.04.B5	Blue Steel Liner 0.6–0.8mm 5Mt
92.04.R3	Red Steel Liner 0.9–1.2mm 3Mt
92.04.R4	Red Steel Liner 0.9–1.2mm 4Mt
92.04.R5	Red Steel Liner 0.9–1.2mm 5Mt
92.04.Y3	Yellow Steel Liner 1.2–1.6mm 3Mt
92.04.Y4	Yellow Steel Liner 1.2–1.6mm 4Mt
92.04.Y5	Yellow Steel Liner 1.2–1.6mm 5Mt
92.04.BT3	Blue Teflon Liner 0.6–0.9mm 3Mt
92.04.BT4	Blue Teflon Liner 0.6–0.9mm 4Mt
92.04.RT3	Red Teflon Liner 0.9–1.2mm 3Mt
92.04.RT4	Red Teflon Liner 0.9–1.2mm 4Mt
92.04.RT5	Red Teflon Liner 0.9–1.2mm 5Mt
92.04.YT3	Yellow Teflon Liner 1.2–1.6mm 3Mt
92.04.YT4	Yellow Teflon Liner 1.2–1.6mm 4Mt
92.04.U5	Universal Liner 0.9–1.2mm 4Mt
92.04.BNL12	Brass Swan Neck Liner 1.2mm 250mm
92.04.BNL16	Brass Swan Neck Liner 1.6mm 250mm



SPX15 SPOOL GUN & SPARE PARTS

Part No.	Description
97.SPX15.4.9	Bossweld 4mt spool gun SPX15 9 pin Plug
97.SPX15.8.9	Bossweld 8mt spool gun SPX15 9 pin Plug
92.02.15.10	ø 10mm Adjustable Tapered Nozzle
92.02.15.CO	ø 12mm Adjustable Conical Nozzle
92.02.15.CL	ø 19mm Adjustable Cylindrical Nozzle
92.01.15.08	Contact Tip 0.8mm x M6 x 6mm dia x 25mm long
92.01.15.09	Contact Tip 0.9mm x M6 x 6mm dia x 25mm long
92.01.15.10	Contact Tip 1.0mm x M6 x 6mm dia x 25mm long
92.01.25.06	Contact Tip Heavy Duty 0.6mm x M6 x 8mm dia x 25mm long
92.01.25.08	Contact Tip Heavy Duty 0.8mm x M6 x 8mm dia x 25mm long
92.01.25.09	Contact Tip Heavy Duty 0.9mm x M6 x 8mm dia x 25mm long
92.01.25.10	Contact Tip Heavy Duty 1.0mm x M6 x 8mm dia x 25mm long
92.01.M6A09	Contact Tip 0.9mm x M6 Aluminium x 8mm dia x 28mm long
92.01.M6A10	Contact Tip 1.0mm x M6 Aluminium x 8mm dia x 28mm long
92.05.15	Tip holder with spring l/hand



BOX CONTENTS

1. Buddy PULSE 200 Inverter Welder

- MIG Torch
- Earth Clamp
- Electrode Holder
- Argon Twin Gauge Regulator
- Gas Hose
- Red Steel Liner for Carbon Steel
- Black Teflon Liner for Aluminium
- 1.0/1.2 Contact Tip Spare for Aluminium
- Gas Diffuser
- Drive Rollers
1.0/1.2mm U Groove (Fitted)
0.8/1.0mm V Groove Spare
0.8/0.9mm Knurled Groove Spare
- 3mm Spanner
- Guide Tube
- Allen Key



NOTE: The manufacturer's liability shall be deemed void if the machine is modified in any way and the manufacturer shall therefore accept no liability for any damages arising as a result of modifications.

WARRANTY

PRIOR TO RETURNING YOUR PRODUCT FOR WARRANTY PLEASE CHECK THE TROUBLESHOOTING GUIDE IN THE PRODUCT INSTRUCTION MANUAL

FOR SERVICE SUPPORT PLEASE CALL (02) 8761 6500

IN ORDER TO MAKE A CLAIM UNDER WARRANTY YOU MUST RETURN THE PRODUCT TO THE ORIGINAL PLACE OF PURCHASE ALONG WITH YOUR PURCHASE RECEIPT.

FAULTY GOODS SHOULD BE RETURNED IN THEIR ORIGINAL PACKAGING ALONG WITH ANY SUPPLIED ACCESSORIES.

2 YEAR WARRANTY

Your product is guaranteed against manufacturing workmanship or defect for a period of 12 months from the original date of purchase. This warranty covers manufacturing defects in materials, workmanship and finish under normal use. If a product is found to be defective we reserve the right to repair or replace at our sole discretion.

No responsibility will be taken for products lost, damaged or mislaid whilst in transit.

To the extent permitted by law this warranty does not cover any indirect or consequential losses and our total liability, if any, shall be limited to the amount paid for the product by you to the retailer.

The benefits provided under this warranty are in addition to other rights and remedies which are available to you under Australian law.

WARRANTY EXCLUSIONS

The following actions will result in the warranty being void:

- Any damage caused by connection to a power supply or voltage other than specified for the machine
- Damage, faults or defects arising from misuse, abuse accidents or alterations
- Failure to perform maintenance or maintain good working condition of the machine or accessories as set out in the instruction manual
- If the machine is disassembled or tampered with in any way
- Fair wear and tear especially to cables, leads etc
- Consumable items such as electrode holders or clamps

This warranty is given by Dynaweld Industrial Supplies Pty Ltd

ABN: 17 050 731 756

Ph.1300 899 710

Australia (Head Office)

2/10 Jessica Place, Prestons, NSW, Australia, 2170