

Rolling Safety Step Insert

Designed for use with Richmond safety step SSR002

Move and transport your safety step with ease

Simply place your step over the insert
and start rolling

Spring loaded castors retract when weight is applied,
meaning the step won't roll off with you on it.



How to Install



Step 01

Take the spring loaded castor and slide the spring down onto the shaft.



Step 02

Slide the shaft of the castor with the spring attached through the mounting hole on the insert from the bottom.



Step 03

Once the shaft of the castor is through the mounting hole, fit the supplied washer from above.



Step 04

Insert the supplied split pin through the hole to secure the castor in place.



Step 05

Place your safety step over the insert ready and you're ready to go.



MADE IN CHINA

1300 474 246

www.richmondau.com

Part No.
SSR003