



TECHNICAL DATA

FL-20 PRIMER

Adhesion Promoter Primer for Flexane Urethane Compounds

Description

FL-20 Primer is a one part moisture cure adhesion promoter primer used on concrete, rubber, wood, fibreglass, PVC and cured epoxy.

Areas of application

- Priming concrete, wood, rubber, fibreglass, PVC and urethane before applying any **Flexane** products

Features

- One part, moisture cure primer which dries in 15-30 minutes

Chemical Resistance

Rating chemical resistance is not necessary for this product.

Technical Data

Typical Physical Properties: Cured 7 days @ 24°C

% Solids by Volume	3.7
Cure Time	15-30 minutes
Coverage (per 120ml)	0.93m ² @ 125µm
Concrete	Adhesion (1 coat): >893 kg/m
Cured Flexane	Adhesion (1 coat): >893 kg/m
Fibreglass	Adhesion (1 coat): >893 kg/m
Polyester	Adhesion (1 coat): >893 kg/m
Rubber	Adhesion (1 coat): >893 kg/m
Metal, immersed in water	1-coat FL-10 followed by 1-coat FL-20

The information contained in this Technical Bulletin is as up to date and correct as possible as at the time of issue. The data provided should be used as a guide only as the performance of the product will vary depending on differing operating conditions and application methods.

The sale of any product described in this Technical Bulletin will be in accordance with ITW Polymers & Fluids Conditions Of Sale, a copy of which is available on request. To the extent permitted by law, ITW Polymers & Fluids excludes all other warranties in relation to this product.

Directions for use

Surface Preparation

Rubber – Thoroughly clean the rubber area with an abrasive pad and **Devcon® Surface Cleaner**. A grinding wheel may be used to roughen the rubber surface. The rubber surface must be coarse and free from oil and dirt clogged in the “pores”. Using **Devcon® Surface Cleaner** wipe or roughen surface until the colour of the rubber substrate no longer appears on cloth. The rubber should look new or a deeper black in colour.

Metal – Thoroughly clean the area that is to be repaired, rebuilt or lined, by using **Devcon® Surface Cleaner**. All oil, grease and dirt must be removed before applying **Flexane** material. All surfaces must be roughened by grinding with a coarse wheel or an abrasive disc pad.

Maximum adhesion – Sandblast the surface using an angular abrasive to achieve minimum depth profile of 50 - 75 microns. Abrasive blast clean in accordance with **Australian Standard AS1627:4-2005** to a Class 2 ½ near white metal finish. After sandblasting, application surface should be primed immediately to prevent oxidation.

Mixing

- Mixing is not applicable to this product.

Application

Many field applications using **Devcon®'s Flexane** technology are unsuccessful because the technician fails to use the proper primers to adhere the **Flexane** to the substrate. There are 2 different priming systems to use when applying **Flexane, FL-10** and **FL-20**, for specific applications one or the other should be applied:

- **Concrete:** Being a very porous surface, concrete needs to have multiple cleaning. Degrease with **Devcon® Surface Cleaner** and rinse multiple times. Let the floor dry thoroughly before applying **FL-20 Primer**. Apply two coats to the concrete for proper adhesion.
- **Rubber:** Apply **FL-20 Primer** to gum rubber, neoprene or cured urethane. One coat is sufficient.
- **Wood/Fibreglass:** One coat on all hardwoods (maple, oak) is sufficient with 2 coats on all softwoods (pine). Fibreglass needs only one coat.
- **Plastics:** Use 2 coats of **FL-20 Primer** to increase adhesion.
- **Dry Time:** Minimum of 15 minutes before topcoating with **Flexane** and a maximum of 2 hours. If exceeded solvent wipe and re-apply.

Storage and Shelf Life

Store in dry conditions between 10°C and 40°C, away from sources of heat and naked flames. Protect from frost. When stored in original sealed containers, the minimum shelf life is one (1) year.

Packaging

FL-20 Primer is available in 120ml tins.

Ordering Information:

120 ml tin

#D15985

Health & Safety Information

The product is hazardous. A Material Safety Data Sheet is available from the ITW Polymers & Fluids Technical Department upon request or available on our website www.itw-devcon.com.au .

AUSTRALIA

ITW Polymers & Fluids
100 Hassall Street
Wetherill Park NSW 2164
Phone (02) 9757 8800 Fax (02) 9757 3855

NEW ZEALAND

ITW Polymers & Fluids
Unit 2, 38 Trugood Drive
East Tamaki 2013, Auckland
Phone (09) 272 1945 Fax (09) 273 6489